

## **GENERAL NOTES**


- 1 S = Normal width of paved shoulder as shown on plans.
- 2 See plans for W
- 3. Mailbox approach pavement section shall be the same as the shoulder material.



## TYPICAL MAILBOX APPROACH



## COMBINATION MAILBOX APPROACH & DRIVE (Mailbox located beyond drive)



## COMBINATION MAILBOX APPROACH & DRIVE (Mailbox located beyond drive)

