

| | |
|------------------------------|---|
| Title | Formaldehyde in Indoor Air |
| Specimen Requirements | Samples for Formaldehyde analysis will only be accepted from the Indiana State Department of Health Indoor Air Division or from a County Health Department. |
| Sampling Materials | <p>Miniature impinger with 15 ml of 1% sodium bisulfite solution (prepared by ISDH Labs)</p> <p>Personal sampling pump, MSA Model G or equivalent, calibrated at 1-2 liters per minute.</p> |
| Procedural Notes | Record total sampling volume or sampling time and pump rate for total volume to be calculated. A minimum air volume of 30 liters is required (100 liters is recommended). A blank sample should be submitted with every set of samples. Mark each impinger and parafilm the impinger nipples. Make sure to note the total air volume sampled. |
| Shipping Instructions | <p>Place impingers in "birdhouse" provided and use foam padding to prevent damage. Hand deliver to ISDH Labs:</p> <p>Indiana State Department of Health Chemistry Laboratories 550 W. 16th Street, Suite B Indianapolis, In 46202</p> |
| Reporting and TAT | Results will be e-mailed to the submitter normally within 30 days. |